

プリンタモデル名	32bit Windows サポート	64bit Windows(x64) サポート
VP-700	○	○
VP-4200	○	○
VP-5200	○	○
VP-2200	○	○
VP-880	○	○
VP-4300	○	○
VP-700U	○	○
VP-1200U	○	○
VP-1850	○	○
VP-F2000	○	○
VP-F4400/F4400N	○	○
VP-6200	○	○
VP-2300	○	○
VP-1900	○	○
VP-930	○	○
VP-930R	○	○
VP-D500	○	○
VP-D1800/D1800N	○	○
VP-D800/D800N	○	○
VP-F2100/F2100N	○	○
VP-F2400/F2400N	○	○
PLQ-20	○	○
PLQ-30S	○	○
LP-1700S	○	○
LP-2200	○	○
LP-2400	○	○
LP-7900	○	○
LP-8100	○	○
LP-8300S	○	○
LP-8300F	○	○
LP-8400	○	○
LP-8400F	○	○
LP-8400FX	○	○
LP-8600F	○	○
LP-8600FX	○	○
LP-8700	○	○
LP-9300	○	○
LP-9400	○	○
LP-1900	○	○
LP-2500	○	○
LP-7000C	○	○
LP-8900	○	○
LP-9000C	○	○
LP-9100	○	○
LP-9200B	○	○
LP-9200C	○	○
LP-9800C	○	○
LP-8600	○	○
LP-V500	○	○
LP-S7000	○	○
LP-S6000	○	○
LP-S4000	○	○
LP-S5000	○	○
LP-S300N	○	○
LP-S300	○	○
LP-S3000	○	○
LP-S2000	○	○
LP-S7500	○	○
LP-S6500	○	○

プリンタモデル名	32bit Windows サポート	64bit Windows(x64) サポート
LP-S4500	○	○
LP-S310N	○	○
LP-S210	○	○
LP-S310	○	○
LP-S340DN	○	○
LP-S440DN	○	○
LP-S3200	○	○
LP-S3500	○	○
LP-M5000	○	○
LP-M5300	○	○
LP-M6000	○	○
LP-M8040	○	○
LP-S5300	○	○
LP-S7100	○	○
LP-S8100	○	○
LP-S9000	○	○
LP-S3250	○	○
LP-S3550	○	○
LP-S4250	○	○
LP-S7160	○	○
LP-S8160	○	○
LP-S280DN	○	○
LP-S9070	○	○
LP-S180DN	○	○
LP-S180D	○	○
LP-S380DN	○	○
LP-S950	○	○
LP-S2290	○	○
LP-S3290	○	○
LP-S3590	○	○
LP-S4290	○	○
LP-S7180	○	○
LP-S8180	○	○
LP-M8180F	○	○
LP-M8180A	○	○
EM-900C	○	○
EM-930C	○	○
MJ-930C	○	○
PM-4000PX	○	○
E-300	○	×
E-300L	○	×
PM-760C	○	○
PM-800C	○	○
PM-800DC	○	○
PM-840C	○	○
PM-850PT	○	○
PM-890C	○	○
PM-900C	○	○
PM-A970	○	×
PX-B500	○	×
PX-B300	○	×
PX-10000	○	○
PX-H10000	○	○
PX-20000	○	○
PX-5800	○	○
PX-6000	○	○
PX-6200S	○	○
PX-6250S	○	○

プリンタモデル名	32bit Windows サポート	64bit Windows(x64) サポート
PX-6500	○	○
PX-6550	○	○
PX-7000	○	○
PX-7500	○	○
PX-7500N	○	○
PX-7500S	○	○
PX-7550	○	○
PX-7550S	○	○
PX-H8000	○	○
PX-9000	○	○
PX-9500	○	○
PX-9500N	○	○
PX-9500S	○	○
PX-9550	○	○
PX-9550S	○	○
PX-W8000	○	○
PX-F8000	○	○
PX-F10000	○	○
PX-5002	○	○
PX-H6000	○	○
PX-H7000	○	○
PX-H9000	○	○
PX-3V	○	○
PX-5V	○	○
PX-5V2	○	○
SC-PX1VL	○	○
SC-PX1V	○	○
EPSON SC-S30600 Series	○	○
EPSON SC-S40600 Series	○	○
EPSON SC-S50600 Series	○	○
EPSON SC-S60600 Series	○	○
EPSON SC-S70600 Series	○	○
EPSON SC-S80600 Series	○	○
EPSON SC-T3000 Series	○	○
EPSON SC-T5000 Series	○	○
EPSON SC-T7000 Series	○	○
EPSON SC-T3200 Series	○	○
EPSON SC-T5200 Series	○	○
EPSON SC-T7200 Series	○	○
EPSON SC-T3100 Series	○	○
EPSON SC-T5100 Series	○	○
EPSON SC-T3400 Series	○	○
EPSON SC-T5400 Series	○	○
EPSON SC-P20000 Series	○	○
EPSON SC-P10000 Series	○	○
EPSON SC-P9000 Series	○	○
EPSON SC-P8000 Series	○	○
EPSON SC-P7500 Series	○	○
EPSON SC-P7000 Series	○	○
EPSON SC-P6000 Series	○	○
EPSON SC-P5000 Series	○	○
EPSON SC-F2100 Series	○	○
EPSON SC-F3000 Series	○	○
EPSON SC-F6200 Series	○	○
EPSON SC-F6400 Series	○	○
EPSON SC-F6400H Series	○	○
EPSON SC-F7200 Series	○	○
EPSON SC-F9200 Series	○	○
EPSON SC-F10000 Series	○	○

プリンタモデル名	32bit Windows サポート	64bit Windows(x64) サポート
EPSON SC-R5000 Series	○	○
EPSON SC-R5000L Series	○	○
EPSON ML-8000		
GP-700	○	×
GP-710	○	×
GP-730	○	○
GP-C831	○	○
GP-M831	○	○
TM-C3400	○	○
TM-C3500	○	○
TM-C7500	○	○
TM-C7500G	○	○
CW-C6020A	○	○
CW-C6020P	○	○
CW-C6520A	○	○
CW-C6520P	○	○